

SENCOR®

SDC 7900 Qi



User's manual

Návod k obsluze

Návod na obsluhu

Használati útmutató

Instrukcja obsługi

NIGHT LIGHT ALARM CLOCK
WITH A WIRELESS CHARGER

BUDÍK S NOČNÍM SVĚTLEM
A BEZDRÁTOVOU NABÍJEČKOU

BUDÍK S NOČNÝM SVETLOM
A BEZDRÔTOVOU NABIJAČKOU

ÉBRESZTŐÓRA ÉJSZAKAI FÉNNYEL
ÉS VEZETÉK NÉLKÜLI TÖLTŐVEL

BUDZIK Z NOCNYM ŚWIATŁEM
I ŁADOWARKĄ BEZPRZEWODOWĄ

EN CZ SK HU PL

FUNCTION BUTTONS



- 1 Child lock setting / atmospheric light button
- 2 Alarm / clock button
- 3 + button
- 4 - button
- 5 Hour
- 6 Time indicator
- 7 Minute
- 8 Power supply connection by a C Type connector
- 9 USB-A output (5V, 1A)
- 10 Charging area
- 11 Lock indicator
- 12 PM indicator (afternoon)
- 13 Alarm 1 indicator
- 14 Alarm 2 indicator

FUNCTION

A. Power supply connection

1. Connect the USB-A cable end to the power adapter, then connect the type C cable end to the alarm clock.
2. All indicators will light up and the alarm clock will switch to the standby mode.

B. Wireless charging

1. Place your phone supporting the wireless charging feature on the top of the alarm clock. If your phone supports this function, phone battery charging process will start. Please check the exact induction coil location with your phone manufacturer to reach the highest possible charging process efficiency.

Tip: The alarm clock should be powered via the supplied charging adapter supporting QC2.0/QC3.0 so that the wireless charging can function correctly.

Caution: Both devices are being heated during the wireless charging process. The charging may be interrupted by an elevated temperature. Remove the phone from the alarm clock charging area before resuming the charging. You can put the phone back once cooled down.

2. **Charging status indicator**

- **blue light:** wireless charging of the placed device is in progress
- **blue fast flashing indication:** a phone not supporting the wireless charging feature is placed on the alarm clock charging area
- **no indication:** no charging is in progress (the charging has finished or no device has been placed)

C. USB

The USB-A (5V, 1A) port is designed to charge devices not supporting the wireless charging.

Caution: The USB port does not support the QC 2.0/QC 3.0 mode transfer.

D. Alarm/clock function

1. Setting the time format:

To toggle between 12-hour or 24-hour time format, tap the Alarm/Clock button. If the 12-hour time format is set, the PM indicator will be shown.

2. Setting the time:

- 1) Tap the Alarm/Clock button once to open the minute setting and adjust the value by +/- button.
- 2) When the minutes are set, tap the Alarm/Clock button once to open the hour setting and adjust the value by +/- button.
- 3) To finish the time setting, tap the Alarm/Clock button the third time.

3. Setting the alarm:

- 1a) To enable or disable alarm No.1, hold down the "+" button for 3 seconds.
- 1b) To enable or disable alarm No.2, hold down the "-" button for 3 seconds.
- 1c) The alarm indicator will light once the alarm is enabled.
- 2a) Hold down the Alarm/Clock button once to open the alarm No.1 minute setting and adjust the value by +/- button.
- 2b) When alarm No.1 is set, tap the Alarm/Clock button to open alarm No.2 setting and adjust the value by +/- button.
- 3) If no action is done, the alarm will sound for 3 minutes and then turn off automatically.
- 4) To switch the alarm clock into the sleep mode, touch any button while the alarm sound is output. The alarm will sound 2 more times after 5 minutes. In the sleep mode, the indicator flashes and the Alarm/Clock button is disabled. To adjust time, long press the "+" to stop alarm No.1 or long press the "-" button to stop alarm No.2. All buttons will function in a normal way.

4. Display brightness:

- 1) The brightness is set to the Automatic mode. The display will light the most between 07:00 and 17:59, moderately between 18:00 and 23:59 and at the least between 24:00 and 06:59.
- 2) You can adjust the brightness one time manually if needed. Use the +/- buttons to set the minimum, medium or maximum brightness. At the above times, the brightness will be matched to the automatic mode again.

5. Night light setting:

The night light can be set in 10 colour modes: white, alternating RGB shades, selected RGB shade colour: red, orange, yellow, green, blue, dark blue, pink. To switch off the night light immediately, please hold down the Ambient light button for 2 seconds.

6. **Child lock setting:**

- 1) The child lock will be disabled automatically if no alarm clock operation is performed for 30 minutes. While the child lock is enabled, the lock indicator is shown on the display. Only the clock indicator is flashing while all touch buttons are disabled.
- 2) To unlock the child lock, tap twice the child lock touch button in the function button area. When the child lock is unlocked, the lock indicator on the display screen will disappear, the clock indicator will stop flashing and all touch buttons in the touch button area will be enabled.

7. **Battery function:**

- 1) A replaceable battery is only designed for the time function backup.
- 2) All functions are disabled when the power is disconnected. The functions will be enabled once the power is connected.

E Note

1. **Caution:** In order to ensure proper function of alarm clock, wireless charging, night light and USB output, the power must be connected via a QC2.0 or QC3.0 adapter. When connected via other 5V adapter, the Qi mode is not supported (the wireless charging speed will decrease).
2. Do not expose the alarm clock to pressure and shocks.
3. Do not disassemble and/or expose the alarm clock to high temperatures and avoid contact with liquids.
4. Do not place the alarm clock in the close proximity to magnetic cards (ID cards, bank cards etc.) with magnetic strips or chips to avoid damage to the card.
5. Please keep a minimum distance of 20cm between this wireless charger and medical implants (pacemakers, cochlear implants etc.) to prevent damage to the medical devices.
6. Make sure to keep a safe distance between children and the alarm clock.
7. Before cleaning the alarm clock, make sure to disconnect the power source. For cleaning, always use a slightly moistened soft cloth. Do not use detergents or abrasive cleaning agents.
8. Operating temperature: 0-45°C.
9. Operating humidity: 20-85% (40°C)
 - The pictures in this manual are for illustrative purposes only. Your product may have a different appearance.
 - Package contents: alarm clock with charging adapter, charging cable, user's manual.
 - The QC2.0/ QC3.0 power adapter is part of the supplied accessories.

TECHNICAL SPECIFICATIONS

Input:	9V/2A / 12V/1.5A / 5V/3A
Power output:	10W (max.)
Charging power output:	15W
Battery Back-Up:	1 x CR-2032 3V
USB Output:	5V-1A (max)
Power Consumption:	18W (max)
Wireless charger power output:	10W (max)
Charging efficiency:	73%
Charging distance:	≤ 8mm
Frequency:	110-205kHz
Dimensions:	141 x 74 x 117 mm (w / h / d)

CHARGING ADAPTER

Manufacturer's name or trade mark, commercial registration number and address:	Shenzhen JiaYu Electronics Co. Ltd, 3/F NO.20 Fengye Five Rd, Fenghuang, village Fuyong Street Bao'an District, Shenzhen, P.R.China
Model identifier:	5751
Input voltage:	AC100 - 240V
Input AC frequency:	50/60Hz
Output voltage:	DC5.0V / DC9.0V / DC12.0V
Output current:	3.0A (5V) / 2.0A (9V) / 1.5A (12V)
Output power:	18.0W
Average active efficiency:	≥80.00%
Efficiency at low load (10 %):	76.00%
No-load power consumption:	≤0.01W

SUPPORTED DEVICES

Qi compliant products.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



The product meets EU requirements.

Hereby, FAST ČR, a.s. declares that the radio equipment type SDC 7900 Qi is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.sencor.com

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.

The original version is in the Czech language.

Address of the manufacturer: FAST ČR, a.s., U Sanitasu 1621, Říčany CZ-251 01

SENCOR®

EN Warranty conditions

Warranty card is not a part of the device packaging.

This product is warranted for the period of 24 months from the date of purchase to the end-user. Warranty is limited to the following conditions. Warranty is referred only to the customer goods using for common domestic use. The claim for service can be applied either at dealer's shop where the product was bought, or at below mentioned authorized service shops. The end-user is obligated to set up a claim immediately when the defects appeared but only till the end of warranty period. The end user is obligated to cooperate to certify the claiming defects. Only completed and clean (according to hygienic standards) product will be accepted. In case of eligible warranty claim the warranty period will be prolonged by the period from the date of claim application till the date of taking over the product by end-user, or the date the end-user is obligated to take it over. To obtain the service under this warranty, end-user is obligated to certify his claim with duly completed following documents: receipt, certificate of warranty, certificate of installation.

This warranty is void especially if apply as follows:

- Defects which were put on sale.
- Wear-out or damage caused by common use.
- The product was damaged by unprofessional or wrong installation, used in contrary to the applicable instruction manual, used in contrary to legal enactment and common process of use or used for another purpose which has been designed for.
- The product was damaged by uncared-for or insufficient maintenance.
- The product was damaged by dirt, accident of force majeure (natural disaster, fire, and flood).
- Defects on functionality caused by low duality of signal, electromagnetic field interference etc.
- The product was mechanically damaged (e.g. broken button, fall).
- Damage caused by use of unsuitable media, fillings, expendable supplies (batteries) or by unsuitable working conditions (e.g. high temperatures, high humidity, quakes).
- Repair, modification or other failure action to the product by unauthorized person.
- End-user did not prove enough his right to claim (time and place of purchase).
- Data on presented documents differs from data on products.
- Cases when the claiming product cannot be indentified according to the presented documents (e.g. the serial number or the warranty seal has been damaged).

Authorized service centers

Visit www.sencor.com for detailed information about authorized service centers.